Item# 12317/12318

Recommended for ages 3+
Please read and follow this instruction manual.
Do not give this watch to a child under 3 years of age.
Adult supervision Required.

Battery information:

Watch A Pet includes 1 x CR2450 3V Button battery.
The battery life is 4-6 months. Button batteries should be kept out of reach of children to avoid accidental swallowing. If button battery is swallowed by mistake please seek medical attention;
When battery is low, please replace the battery responsibly.
Use a Phillips screwdriver to open the cover on the back of the watch to replace it. Only use a CR2450 3V button battery.
The battery should be inserted with the correct polarity (+,-);
Do not use damaged batteries. The power terminals must not be shot-circuited;
When not in use for a long time, please remove battery.
Note: This product cannot use re-chargeable batteries!



Care information:

We want to make sure that your child is comfortable wearing theirnew Watch A Pet and loves playing and learning with it. Here are a few tips that should help:
- Keep your child's watch loose enough so that two of your fingers can fit underneath the watch while it's being worn. Wearing it too tight can cause skin irritation due to sweat and moisture. Kids with eczema or a skin condition should consult with physician before wearing the watch.
- Clean your band regularly, especially after strenuous exercise. It is recomended to remove and rinse the band with water, or wipe it with a alcohol wipe. Do NOT use any kind of soap, hand sanitizer or household cleaners as they could get trapped beneath the band and irritate the skin.
- After cleaning, set your watch aside for 10-15 minutes to ensure it is dry and free of any potential irritants.
- For stains or buildup on your band and casing, wipe gently with an alcohol wipe.
- To keep you watch looking new, use a microfiber cloth to wipe off smudges or fingerprints from casing, screen and band.
- You watch should always feel great, but if you experince irritation, please remove the watch and consult a physician.

How to remove the strap:
Push the protrusions on the back of the strap inward until the strap comes off.



Watch functions:

To set the time, navigate to the settings menu using the left and right buttons. Hit the OK button to enter the settings menu. Hot the right button once, to access the "time setting" menu. Hit OK to enter. Select between 12 / 24 hour format and hit OK. Then use the left and right buttons to set the correct time and hit OK to confirm.

To change the main clock face, navigate to the settings menu using the OK button. Hit the left and right buttons to select the clockface you want. There are 6 dials to choose from.
Hit OK button To confirm selection.



How to care for your pet:

Choose one of the 4 baby animal pet options: Cat, Dog, Rabbit, or Bear.
When the baby is crying, the watch will make a sound and the OK button will flash, indicating that the baby needs to be fed or changed. Hit the OK button to view the baby's growth bar. When the growth bar is full, the baby will grow into a teenager. You will need to interact with your pet based on what is displayed on the screen.

When the baby grows into a teenager, hit OK call out the interactive function, and you can check the pet's health bar at any time.

- **HEALTH -** Which will decrease if the pet does not get enough food or enough sleep.
- **MOOD -** Which will decrease if you don't play games.
- **CLEANLINESS -** Which will improve by taking a bath and going to the toilet.
- When the tooth icon appears on the screen, you must brush your pet's teeth.
- When your pet touches its belly with one hand, it means it is hungry and needs to eat.
- When your pet has an aggreived expression, it means it is unhappy and wants to play a game.
- When your pet is waving its arms, it means it is dirty and needs a bath.
- When your pet covers its belly with both hands, it means that it needs to go to the toilet.
- When your pet yawns, it means that it is sleepy and wants to sleep.
- You can touch your pet's head at any time and it will be very happy.
- If you want to change your pet, select the reset function. Please note that if you select a new pet, your new pet will begin as a baby.

Applications & Games

ALARM CLOCK - Hit the left and right buttons to turn on the alarm clock. When the alarm icon is X, the alarm is turned off. Hit OK to switch options down. The last option is the prompt music, there are three kinds of music to choose from.

COUNTDOWN - Hit the left and right buttons to increase or decrease the minutes, and then hit OK button to switch to seconds. After setting the time, hit OK button to start. If you hit the OK button again, the countdown will stop.

STOPWATCH - Hit OK to start timing, and hit OK again to stop timing. Hit the return button to return to the main clockface.

GAMES - Watch A Pet includes three educational games: 1) Food Alhabet, 2) Shape finder, & 3) Safe Landing. See game instructions below.

FOOD ALPHABET
Select the correct food that begins with the letter that is displayed.

SHAPE FINDER
Find and select all the shapes that can fill-in the outline by hitting the left and right buttons and hitting the OK button.

SAFE LANDING
A calculation questions will appear. Hit OK to select the answer. If you select the correct answer, the bear will have a safe landing. If you get it wrong, try again.

Troubleshooting

If there is a sudden crash during the game, please follow the steps below to troubleshoot.
1) Turn off the host;
2) Take out the battery and interrupt power supply;
3) After a few minutes, re-install the battery and restart.
4) If problem persists, please replace the battery.

Jupiter Creations

© 2022 Jupiter Creations, Inc. All rights reserved
www.jupitercreations.com